



The CSP-1 Kit Consists of:
1 TLP-102 Telephone Patch
1 CSP CD
1 Software Registration Code

11636 GOLDRING RD • ARCADIA, CALIFORNIA 91006-5815
626-358-2559 • FAX 626-359-5701 • 800-525-6925

Installation Instructions for Call Saver® Pro™ CSP-1 Telephone Recording Kit

The CSP-1 Telephone Recording Kit lets you record your telephone calls on your computer. It provides clear recordings of both sides of your phone conversations. The TLP-102 Telephone Recorder Patch connects to the telephone via the modular handset connector as detailed below.

INSTALLATION INSTRUCTIONS

- 1 Unplug the coil cord from the base of the phone and plug it into the Handset jack on the TLP-102.
- 2 Plug the short cable from the TLP-102 into the phone base where the coil cord was plugged.
- 3 Plug the pink plug on the long cable into the MIC jack on your computer.
- 4 Insert the Call Saver Pro disk into your computer's disk drive and follow the automated instructions to install the software on your PC.

Follow the instructions included in the Call Saver® Pro™ software for recording with your PC.

**Instructions for CSP-1
Telephone Logger Patch
& Call Saver Pro™ Call Recording Software**

